


Connecting a CP-4 to a Ghost Control Gate Opener



White wire to COM

Blue wire to OPEN

(CP-4 Voltage ranges = 8-24 VAC or 8-30 VDC)

Red wire to a constant power source. Unit will run on AC or DC. Need to observe polarity only if DC, Red to positive (+).

Black wire to a constant power source. Unit will run on AC or DC. Need to observe polarity only if DC, Black to negative (-).