


CP-4 to Viking E-4 Wiring Diagram

refer to "Appendix (A)" on pages 37-38.



CP-4

Red Wire on Loop Connector +28V


Black Wire on Loop Connector GND (Ground)

White Wire on Guard Station GND (Ground)

Blue Wire on Guard Station OPEN

Yellow Wire is not used.

Wiring for CP-4 to Viking R-6



Yellow wire is not needed